

**westcoat®****PRODUCT  
SPECIFICATION****CA****ACCESSORIES**  
ADDITIVES & ACCESSORIES**CA-50 Stone Strips®****Description**

Westcoat's CA-50 Stone Strips® are pre-cut individual strips that can simulate a flagstone pattern when laid out to form patterns prior to applying a skip troweled texture coat on cementitious coatings. Stone Strips® have an adhesive back side and the strips are applied to the Grout Coat in a random flagstone pattern, then a Texture Skip Trowel coat is applied over the strips. When the strips are removed, it will leave a 3-dimensional texture and simulated grout pattern, mimicking the look of Flagstone.

**Uses**

CA-50 is designed to be used with a variety of Westcoat's custom finish systems like Texture-Crete Custom Finish, ALX Custom, ALX Pro Custom and MACoat Custom. Some uses include driveways, walkways, patios, courtyards, entryways, showrooms and pool decks.

**Advantages**

Ease of Application • Pre-Cut Sizes and Designs • Creates a 3-Dimensional Texture • Simulates a Random Flagstone Design

Product Data			
<b>Packaging</b>	~500 square feet per Box	<b>Colors</b>	White
<b>Coverages</b>	~500 square feet/box	<b>Mix Ratio</b>	N/A
<b>VOC Content</b>	0 gm/l	<b>Shelf Life</b>	1 year in unopened packaging

**Inspection**

Surface must be prepared in the proper manner that is required in the System Specification sheet for the desired application.

**Preparation**

Refer to the appropriate System Specification sheet prior to installation for preparation instructions.

**Coverage**

Coverage is approximately 500 square feet per box when laid out in a random Flagstone Pattern.

**Application**

Apply CA-50 Stone Strips® to the Grout Coat of the desired Custom Finish System prior to applying the Texture Skip Trowel coat. Ensure the Grout Coat is dry, clean and free of any debris, before application. Peel the backing off an individual Stone Strip® and apply it to the Grout Coat. Continue adding other strips to form a random Flagstone Pattern. Make sure the strips are rubbed down very well, to eliminate any bleeding from the Texture Coat. Apply the Texture Skip Trowel coat per desired System Specification Sheet instructions. Remove the Stone Strips® once the Texture Coat is dry. For best results, do not leave the CA-50 down for longer than 24 hours.

**Limitations**

- Do not apply to damp or wet surfaces.
- This product is designed for professional use only, by experienced applicators.

DISCLAIMER: PURCHASER'S SOLE AND EXCLUSIVE REMEDY AGAINST THE MANUFACTURER OF WESTCOAT, SHALL BE LIMITED SOLELY TO THE REPLACEMENT OF ANY DEFECTIVE MATERIAL OR A PAYMENT BY THE MANUFACTURER IN AN AMOUNT EQUAL TO THE COST OF THE ORIGINAL MATERIAL.

**westcoat®**

4007 Lockridge St • San Diego, CA 92102  
800-250-4519 • Fax 619-255-7187 • westcoat.com

1 of 1  
CA-50 4/25