



CA-60 Grout Tape

Description

Westcoat's CA-60 Grout Tape is a reinforced, heavy duty tape available in varying widths that can simulate a tile pattern when laid out to form patterns prior to applying a skip troweled texture coat on cementitious coatings. Grout Tape has an adhesive back side and the tape is applied to the Grout Coat in a tile pattern, then a Texture Skip Trowel coat is applied over the tape. When the tape is removed, it will leave a 3-dimensional texture and simulated grout pattern, mimicking the look of tile.

Uses

CA-60 is designed to be used with a variety of Westcoat's custom finish systems like Texture-Crete Custom Finish, ALX Custom, ALX Pro Custom and MACoat Custom. Some uses include driveways, walkways, patios, courtyards, entryways, showrooms and pool decks.

Advantages

Ease of Application • Varying Widths • Creates a 3-Dimensional Texture • Simulates a Tile Pattern Design

Product Data			
Packaging	Individual Roll or Case Pack	Widths	1/4", 1/2" and 3/8"
Coverages	~55 linear yards/roll	Mix Ratio	N/A
VOC Content	0 gm/l	Shelf Life	1 year in unopened packaging

Inspection

Surface must be prepared in the proper manner that is required in the System Specification sheet for the desired application.

Preparation

Refer to the appropriate System Specification sheet prior to installation for preparation instructions.

Coverage

Coverage is approximately 500 square feet per box when laid out in a random Flagstone Pattern.

Application

Apply CA-60 Grout Tape to the Grout Coat of the desired Custom Finish System prior to applying the Texture Skip Trowel coat. Ensure the Grout Coat is dry, clean and free of any debris, before application. Decide on the width and size of the tile pattern desired and apply the Grout Tape to the Grout Coat. Keep adding additional tape to form the desired Tile Pattern. Make sure the tape is rubbed down very well, to eliminate any bleeding from the Texture Coat. Apply the Texture Skip Trowel coat per desired System Specification Sheet instructions. Remove the Grout Tape once the Texture Coat is dry. For best results, do not leave the CA-60 down for longer than 24 hours.

Limitations

- Do not apply to damp or wet surfaces.
- This product is designed for professional use only, by experienced applicators.

DISCLAIMER: PURCHASER'S SOLE AND EXCLUSIVE REMEDY AGAINST THE MANUFACTURER OF WESTCOAT, SHALL BE LIMITED SOLELY TO THE REPLACEMENT OF ANY DEFECTIVE MATERIAL OR A PAYMENT BY THE MANUFACTURER IN AN AMOUNT EQUAL TO THE COST OF THE ORIGINAL MATERIAL.

