

## **KEYNOTES**

- 1) Plywood (by others)
- (2) WP-40 Sheet Membrane (6" or 36")
- (3) Bonderized Metal Flashing
- (4)WP-25 Metal or WP-30 Glass Lath
- (5) Base Coat
- 6 WP-95 Membrane & Fabric (Pro System)
- 7 Body Coat
- 8 Texture Coat & Topcoat

POST TO BE INSTALLED ON TOP OF BODY COAT.
A TEXTURE COAT MUST BE APPLIED AFTER POST
FLANGE INSTALL

## IAPMO ER - 517

- Standard overlap is bottom to top with a 4" overlap.
- Apply WP-53 on all flashing seams and overlaps.
- Minimum 5/8" exterior grade plywood.
- Minimum 1/4" slope required on all decks
- Refer to local building codes and standards.
- •Refer to system and product specification sheets.
- Shows best option for top mount. Side mount is recommended for all railings.

All details are for reference only and should be evaluated by architect. These details are not a substitute for specifications, plans or evaluation reports. Architect, consultant or similar professional should be review prior to major waterproofing applications.

## SHUR DECK SYSTEM - TOP MOUNT RAILING

DIVISION 07 18 13 Pedestrian Traffic Coatings

SCALE: NTS



## westcoat.

SPECIALTY COATING SYSTEMS

4007 Lockridge Street • San Diego, CA • 92102 800.250.4519 • westcoat.com